

## Pontiac G8 High Flow Air Intake Hose Coupler Configuration



*Yellow couplers used for clarity only*

Use the standard G8 CAI installation instructions for the air box assembly, inlet elbow breather pre-assembly and installation of the air box into the car. Install and clamp one of the step hose couplers on the throttle body and the other on the air box adapter duct. When inserting the MAF sensor housing, be sure the flow direction arrow on your sensor will be pointing towards the motor. The smaller end of the step hump hose will engage the "motor side" or the outlet of the MAF sensor housing. The 3/8" ID breather hose will route as shown in the standard instructions.